

W-DMX

MODULE



MERLIN Option

VALIDATION : 07/04/15



ROBERT JULIAT

DN41077000

Robert Juliat S.A.S. 32, rue de Beaumont, F 60530 Fresnoy-en-Thelle - phone : +33 (0)3 44 26 51 89 - fax : +33 (0)3 44 26 90 79 - info@robertjuliat.fr

www.robertjuliat.com

Precautions:

- Protocol: Wireless Solution W-DMX™
- Refer to the OEM User's manual for general recommendations and use of the transmitter: <http://www.wirelessdmx.com>
- The antenna must be clearly visible from the transmitter.
- See *MENU* for activation in the MERLIN user's manual.
- **Do not connect a DMX IN data cable in case of wireless DMX use**
- In case of protocol errors, the wireless DMX is automatically deactivated. To activate the wireless DMX again, disconnect the DMX IN data cable, and then switch the unit off and on.

**Installation:**

- Remove the power supply from the followspot head.
- Insert the W-DMX module into the slot.
- Reconnect the power supply unit.



Robert Juliat reserve the right to change or alter any of the items detailed on this page,
to increase or improve manufacturing techniques without prior notice.

Précautions :

- Protocole: W-DMX™ Wireless Solution
- Reportez-vous au manuel utilisateur du fabricant pour des recommandations générales et utilisation de l'émetteur : <http://www.wirelessdmx.com>
- L'antenne doit être clairement visible de l'émetteur.
- Pour activer le wireless, se reporter à la section *MENU* du manuel utilisation MERLIN.
- **Ne pas connecter un câble data DMX IN dans le cas d'une utilisation sans fil DMX.**
- En cas d'erreurs de protocole, le DMX sans fil est automatiquement désactivé. Pour activer à nouveau le DMX sans fil, débranchez le câble data DMX IN, puis éteindre l'appareil et le rallumer.

**Installation :**

- Retirer le bloc d'alimentation.
- Insérer le module W-DMX dans la fente.
- Reconnecter le bloc d'alimentation.

